

KENCO ENGINEERING COMPANY

P.O. BOX 470426 TULSA, OK 74147-0426
PHONE: (918) 663-4406 FAX: (918) 663-4480

Web: www.kenco-eng.com e-mail: info@kenco-eng.com

507-K INSTALLATION AND MAINTENANCE INSTRUCTIONS

1. Remove the cover plate from the extra pump pocket and insert the controller into the pump pocket. The safety switch must be on pump side of lubricator.
2. The oil supply tank must be at least 24" and not more than 60" above controller inlet. The supply system must be clean. It is recommended that the oil supply lines are flushed to remove any debris which could interfere with the correct operation of the controller. The minimum recommended supply line size is 1/2" I.D.
3. Connect the wire from the controller terminal to the low tension terminal on the magneto. After installing, the safety switch action should be checked by draining all oil from the lubricator. If the switch fails to stop the engine, it should be adjusted.

P.O. BOX 470426, TULSA, OK 74147-0426 PHONE:(918) 663-4406 FAX:(918) 663-4480
<http://www.kenco-eng.com>