

KENCO ENGINEERING COMPANY

P.O. BOX 470426 TULSA, OK 74147-0426

PHONE: (918) 663-4406 FAX: (918) 663-4480

Web: www.kenco-eng.com e-mail: info@kenco-eng.com

MODEL KEFS LIQUID LEVEL FLOAT SWITCH FLOAT REPAIR KIT INSTRUCTIONS.

RK-FS4-KEFS; RK-FS6-KEFS, FLOAT REPAIR KIT

To install new Float, remove old Float from KEFS and make sure the threads on the Float Counterweight are clean and dry. Thoroughly shake the supplied bottle of Thread Locking compound and apply liberally to the threads of the Float Counterweight and the Float. Screw the Float onto the Float Counterweight and tighten firmly. If the supplied or one of the optional Float Extensions is used, apply the Threadlocker to the threads on both ends of the Extension. Thread the Float Extension onto the Float and then thread the assembly onto the Float Counterweight and tighten firmly. Wipe off any excess threadlocker. Reinstall switch. Threadlocker will achieve full cure in 24 hours.

