

# KENCO ENGINEERING COMPANY

P.O. BOX 470426 TULSA, OK 74147-0426

PHONE: (918) 663-4406 FAX: (918) 663-4480

[www.kenco-eng.com](http://www.kenco-eng.com) e-mail: [info@kenco-eng.com](mailto:info@kenco-eng.com)

## REPAIR KITS FOR SAFEGUARD

### GAUGE GLASS REPAIR KIT MODEL #

62/75-RK-(OAL)-(O-RING SEAL MATERIAL)-(SIGHT TUBE OPTION)

### GLASS REPAIR KITS- CONSIST OF THE FOLLOWING:

- (1) 5/8" O.D. SIGHT TUBE
- (2) O-RING SEALS
- (X) SIGHT TUBE ISOLATORS (QUANTITY BASED ON LENGTH)

OAL = OVERALL LENGTH OF GAUGE IN INCHES (EXAMPLE: 0.000)

### O-RING SEAL MATERIAL OPTIONS

- V = FLUOROCARBON
- A = AFLAS
- B = BUNA-N
- E = FLUOROCARBON
- T = PTFE

### STANDARD SIGHT TUBE OPTIONS

- GS = 5/8" O.D. STANDARD GAUGE GLASS
- HP = 5/8" O.D. HIGH PRESSURE GAUGE GLASS
- HW = 5/8" O.D. HEAVY WALL GAUGE GLASS
- RL = 5/8" O.D. TRUE REDLINE GAUGE GLASS
- GSRL = 5/8" O.D. STANDARD GAUGE GLASS WITH REDLINE ADHESIVE TAPE
- HPRL = 5/8" O.D. HIGH PRESSURE GAUGE GLASS WITH REDLINE ADHESIVE TAPE
- HWRL = 5/8" O.D. HEAVY WALL GAUGE GLASS WITH REDLINE ADHESIVE TAPE

### SHIELD REPAIR KIT MODEL #

62/75-(OAL)-(SHIELD STYLE)

OAL = OVERALL LENGTH OF GAUGE IN INCHES (EXAMPLE: 0.000)

### SHIELD STYLES:

- L = CLEAR POLYCARBONATE
- H = HEIGHT SCALE
- RH = RATE SCALE & HEIGHT SCALE
- MRH = METRIC RATE HEIGHT SCALE
- MH = METRIC HEIGHT SCALE
- M = EXPANDED METAL